

# Operational Instructions

## Combination Units with SpinTec™ Showerhead and HALO™ Eyewash



- 1 Stand under the drench shower.
- 2 Pull the triangular rod to activate the drench shower.
- 3 Remain under the shower and eyewash for a 15-minute continuous flush.
- 4 Hold eyelids open and roll eyeballs back and forth.
- 5 Remove clothing while drenching.
- 6 Seek medical attention.

### U.S. Code of Federal Regulations 29 CFR 1910.151

OSHA states: “Where the eyes or body of any person may be exposed to injurious or corrosive materials, suitable facilities for quick drenching or flushing of the eyes and body shall be provided within the work area for immediate emergency use.”

### American National Standards Institute (ANSI) Z358.1-2009

ANSI establishes standards for minimum performance and use requirements for eyewash and shower equipment. To ensure you are meeting the necessary requirements, review the entire ANSI standard in detail.

Please contact Bradley if you have any questions regarding Bradley’s emergency fixtures and how they comply with the ANSI standard.

1 800 BRADLEY    bradleycorp.com  
W142 N9101 Fountain Boulevard  
Menomonee Falls, WI 53051  
4028-0213

